

Input/battery switching and switch terminal grounding rationale: https://www.freestompboxes.org/viewtopic.php?t=32540

Briefly:

- Input TIP SWITCH and SLEEVE are connected to negative supply, input RING is connected to circuit ground.

- When an input cable is not plugged in, the effect circuit is open (off) due to lack of a return to ground.

- When a TS input cable is plugged in, RING shorts to SLEEVE and completes the circuit from negative supply to ground, energizing the circuit.

- Note that a TRS cable will not complete the circuit, and the effect will remain off.

Battery vs DC supply switching works similarly:

- When a DC source is not plugged into the jack, a BATTERY_POS is connected to the DC_SHIELD net.

- When a DC source is plugged in, the switch opens the battery circuit to providing an alternate positive supply.

Otherwise:

- Output tip (signal) switch IS NOT grounded, as grounding the output of the circuit when energized could damage effect circuit components.

- Input tip (signal) switch IS grounded, to prevent an output signal from being produced when no input cable is

present.

github.com/whbeers/noise_floor

Sheet: /
File: noise floor.kicad sch

Title: Noise Floor Interface Boards

 Size: A4
 Date: 2023-03-23
 Rev: v0.21

 KiCad E.D.A. kicad 7.0.1
 Id: 1/1